
heavy subfloors (e.g. 48 in joist spacing), workbench tops

Measure each sheet before cutting joints.